


# HyspIRI-TIR Calibration Approach

Marc C. Foote, William R. Johnson,  
Simon J. Hook



National Aeronautics and  
Space Administration

**Jet Propulsion Laboratory**  
California Institute of Technology  
Pasadena, California



National Aeronautics and  
Space Administration

Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# Calibration Overview

---

- Spectral Calibration
  - Radiometric Calibration
  - Spatial Calibration
  - On-Orbit Calibration
-




National Aeronautics and  
Space Administration


Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# Spectral Calibration with Monochromator

## Monochromator Assembly



## TIR Instrument



- Heritage (JPL) – PMIRR, TES, MCS, Diviner
- Straightforward approach with reliable results.
- Only a small number of pixels are measured at once. Very time intensive to measure all pixels over full spectral range.




National Aeronautics and  
Space Administration


Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# Spectral Calibration with FTIR

## FTIR (Conceptual) Assembly



## TIR Instrument



TIR Detector  
Signals



National Aeronautics and  
Space Administration

Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# FTIR Spectral Calibration

---

## **Heritage:**

- AIRS
- OCO

## **Advantages:**

- All pixels and wavelengths measured simultaneously
- Automatic spectral calibration to Helium Neon laser standard wavelength (632.8nm)

## **Disadvantages:**



- Requires stepping of FTS to be synchronized with sampling of TIR detectors, or cumbersome post analysis.
-



National Aeronautics and  
Space Administration

Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# Radiometric Calibration



- Performed in vacuum to prevent condensation on cold blackbody surfaces.
- Scan mirror rotates to scan between internal blackbody, cold blackbody, and variable temperature blackbody.
- Variable temperature blackbody is stepped over entire scene temperature range.
- System nonlinearities can be determined using measured spectral response and blackbody response.
- NETD determined by temperature response and noise level.



National Aeronautics and  
Space Administration

Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# Calibration of Blackbody Source

---


- Cavity temperature will be determined using NIST-traceable sensors.
  - NIST Thermal Infrared Transfer Radiometer (TXR) may be used to compare blackbody to NIST standard blackbody.
-



National Aeronautics and  
Space Administration

Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# Spatial (FOV) Calibration



- For cross-scan FOV measurements (slit out of page), TIR scan mirror will sweep slit across focal plane.
- For along-scan FOV measurements (slit vertical on page), slit will be scanned in perpendicular direction (perpendicular to page) to map out focal-plane FOV.



National Aeronautics and  
Space Administration

Jet Propulsion Laboratory  
California Institute of Technology  
Pasadena, California

# On-Orbit Calibration

---

- Two-point calibration, using space and an ambient temperature blackbody, will be performed every 2.3 seconds.
  - Detector specs limit  $1/f$  noise over 2.3 second period.
  - Data stream will include averaged values of space and blackbody readings for each pixel.
  - Nonlinearities measured during ground calibration will be incorporated into calibration algorithm (performed on ground).
-